



PARTS LIST	
ITEM	DESCRIPTION
1	SO2 Chamber
2	Control Panel
3	Hood
4	Chamber Lid
5	Fresh Air Inlet
6	Chamber's Drain Compartment
7	Deionizer
8	Wet Scrubber
9	SO2 Cylinder
10	Air Conditioner
53	

■ SO2 Inlet
■ Chamber's Drain
■ AC Power Connection
■ Distilled / Deionized Water Inlet

